

KHS Mocha / Latte Folding Instructions

Thank you for purchasing a KHS Mocha or Latte folding bike. This guide will show you step-by-step how to best fold your bike. With some practice, you can easily fold the bike within 20-30 seconds!

If you have any questions, please contact your friendly KHS dealer for assistance.



1. Fold the right-side pedal by first pressing in the pedal from the outer edge, then fold it into the vertical position.



2. Rotate the crank so that the folded pedal is pointing toward the rear wheel.
(For Latte, you have to lift up the rear wheel off the ground and rotate the crank in the forward direction)

3. Hold one hand onto the handle bar. Open the quick-release on the head-stem with the other hand.
(NEED TO ADD QUICK-RELEASE USAGE INFO + ADJUSTMENT INFO)



4. Turn the quick-release lever onto a horizontal position (circled) to disengage the safety latch, then fold down the head-stem. If you have a Mocha, be careful that the cables do not snag on the folding mechanism.

KHS Bicycles

800-347-7854 ■ 2840 E Harcourt St ■ Rancho Dominguez, CA 90221

KHS Mocha / Latte Folding Instructions

5. Return the kickstand to the up position, if not already there. Make sure to kick at the release lever (circled in the picture).



6. Open the quick-release on the main body. Then turn the quick-release lever toward the back end of the bike.

7. Pull up on the quick-release lever to release the safety pin, thus un-latching the folding mechanism.



8. Fold the bike in half. If you have Mocha, be careful that the cables do not snag on the folding mechanism.

CONGRATUATIONS!

You have successfully folded your bike!!

To un-fold the bike, simply reverse the folding instructions.

KHS Bicycles

800-347-7854 ■ 2840 E Harcourt St ■ Rancho Dominguez, CA 90221